

Instructions for Wireless Presenter
(works up to 60 ft away)



Remove adapter and plug into USB port of your laptop

Start up your PowerPoint slideshow.

Use this button (laser beam) to point to something on your slide



Use this button to advance your slides

Use this button to go back to a previous slide

Use this button to black out the screen (hide the slide)



When finished, remove adapter from USB port of your laptop and put it back in its holder.