



USING THE EXTRON CONTROL SYSTEM

LAPTOP COMPUTER

- Lower Screen
- Connect the 15-pin Computer cable to right side of the Laptop
- Turn on laptop (plug in power adapter)
- Turn Projector ON: (Press POWER button on EXTRON unit located in rack cabinet for 5 seconds. Release button; Red light will flash; you should hear the Projector fan come on. Projector lens will fill with Blue Light)
- Select Input on EXTRON unit: **PC 1**



15 pin Computer cable



NOTE: If the image does not appear on the Screen, use the FUNCTION key (FN + F7) on the Laptop to “toggle” the setting so the image appears on BOTH the Laptop and Screen



- Adjust room lights as necessary using control switches on the wall
- When you are finished:
 - Turn laptop off and disconnect all cables and cords
 - Turn Projector OFF: (Press POWER button on EXTRON unit for 5 seconds; Release. Red Light will flash on EXTRON unit for about 15 seconds. Projector light will go OFF)
 - Raise Screen



VIDEO

- Lower Screen
- Turn Projector ON: (Press **POWER** button on EXTRON unit located in rack cabinet for 5 seconds. Release button; Red light will flash; you should hear the Projector fan come on. Projector lens will fill with Blue Light)



- Select **VCR** on Extron unit
- Turn VCR “ON”
- Insert videotape; (tape may start to PLAY automatically if the Record Tabs have been removed.)
- Use Variable Control knob on Extron unit to adjust volume
- Adjust lights as necessary using control switches on the wall



When you are finished:



- Press **STOP** ; Turn outer ring on VCR to REWIND
- Press EJECT ; remove videotape
- Turn VCR “OFF”
- Turn Projector OFF: (Press **POWER** button on EXTRON unit for 5 seconds; Release. Red Light will flash on EXTRON unit for about 15 seconds. Projector light will go OFF)



- Raise Screen

DOCUMENT CAMERA (ELMO)

- Lower Screen
- Connect cable to RGB Out on ELMO unit
- Turn Projector ON: (Press **POWER** button on EXTRON unit located in rack cabinet for 5 seconds. Release button ; Red light will flash ; you should hear the Projector fan come on. Projector lens will fill with Blue Light)
- Select Input on EXTRON unit: **PC 2**
- Turn ELMO unit **ON** by pressing Power Switch located on upper right corner (ELMO takes a few seconds to do an internal check .Upper Lights come on automatically- Switch to BASE lights if you are using a clear transparency.)



(To use **BOTH** the ELMO unit and a **LAPTOP COMPUTER**:

- **Connect ELMO as above**
- **Use a second 15-pin computer cable to connect the Laptop Computer to the RGB 1 Input on the back of the ELMO**
- **Press the switch marked RGB1 on Front of the ELMO to display the Laptop image**
- **Press the switch marked MAIN on Front of the ELMO to display the ELMO image)**
- Adjust room lights as necessary using control switches on the wall
- When you are finished:
 - Turn ELMO unit **OFF** and disconnect cable from unit ;
 - Turn Projector OFF: (Press **POWER** button on EXTRON unit for 5 seconds; Release. Red Light will flash on EXTRON unit for about 15 seconds. Projector light will go OFF)
 - Raise Screen

