


Instructions for Wireless Presenter/Mouse



The various mode features are listed in the table below.

Button	Mouse Mode	Presentation Mode
1	Left click	Page up
2	Right click	Page down
3	Internet page forward	Start/Stop
4	Internet page backward	Screen go dark
5	Cursor control	No function
6	No function	Laser Pointer
7	↓ = Mouse mode	↑ = Presentation mode
8	↑ = On / ↓ = Off	↑ = On / ↓ = Off