

Rear-Projected SMART Board

- You need a Laptop that has the SMART Board software installed on it. (CR has install it for you.)
- The laptop must be connected to the Board by a USB adapter.
- Press the POWER button on the SMART board.
- The first time you use your laptop, press both the keyboard and mouse button (bottom right corner of the board) at the same time and follow the on screen directions. This will not be necessary with your use the same laptop again.
- To write on the board, just pick up a pen and write on the board with that color.
- To erase, pick up the eraser (on the bottom left). To erase a lot of text, circle the area to be erased and tap the eraser in the center.
- To launch an application, DOUBLE TOUCH its icon with your finger. However, if you write directly pen on the screen with your pen first, you are creating an invisible layer to write on. So your first touch will erase it. In other words, you will need to touch 3 times to launch an application.
- If you want to save what you have written on the screen, use the Area Capture tool (from the Floating Toolbar).
- You can use Smart notebook software, Word, Excel to add annotations.
- When you use PowerPoint, you must be in the slideshow mode (F5) to annotate. A new toolbar appears that allows you to advance slides by hitting the arrow or add a blank slide (middle button) to add annotations. If you do not use the arrow, you must DOUBLE TOUCH the screen to advance slides.